

64 GDS Helpsheet



*World Leaders in Computer Controlled Testing
Systems for Geotechnical Engineers and Geologists*

Hardware

STD & ADV Controllers

Problems with Membrane Keypads

1. Introduction

If the keypad is not responding to key presses then refer to helpsheet number 8 'Checking connectors and setting 5 volts'. This will ensure that all of the connectors are correctly in place.

If the problem is not corrected by following this procedure then you can find out if the problem is on the main PCB or is associated with the keypad by swapping a top-plate from another controller - see helpsheet: Trouble shooting and faultfinding'.