

135 Helpsheet



*World Leaders in Computer Controlled Testing
Systems for Geotechnical Engineers and Geologists*

Hardware

Serial Cables

Serial Cable Pin Specifications

This helpsheet provides specification for a standard serial cable to connect the following GDS Devices: standard controller, serial advanced controller, RS232 Mux, DI Mux and Serial Pad. Pins not mentioned are not used.

1. 25 Way to 25 Way Cable

This cable connects between a 25 way male connector on an IBM PC and a 25 way female on the device.

The connections of the **cable** are as follows:-

IBM End 25 way Female	to	GDS END 25 way Male
1.....		1
2.....		2
3.....		3
4.....		4
5.....		5
6.....		6
7.....		7
8.....		8
20.....		20
22.....		22

2. 9 Way to 25 Way Cable

This cable connects between a 9 way male connector on an IBM PC and a 25 way female on the device.

The connections of the **cable** are as follows:-

IBM End 9 way Female	to	GDS END 25 way Male
1.....		8
2.....		3
3.....		2
4.....		20
5.....		7
6.....		6
7.....		4
8.....		5
9.....		22